

Microwave Multiplexed Readout of Transition Edge Sensors for Neutrino Detection

Steven J. Weber¹, Kevin K. Ryu¹, Cyrus F. Hirjibehedin¹,
Sarah Trowbridge Heine², William D. Oliver^{1,2}, Joseph A. Formaggio²

¹MIT Lincoln Laboratory & ²MIT Physics Department

11/11/2019

DISTRIBUTION STATEMENT A. Approved for public release. Distribution is unlimited.

This material is based upon work supported by the Under Secretary of Defense for Research and Engineering under Air Force Contract No. FA8702-15-D-0001. Any opinions, findings, conclusions or recommendations expressed in this material are those of the author(s) and do not necessarily reflect the views of the Under Secretary of Defense for Research and Engineering.

© 2019 Massachusetts Institute of Technology.

Delivered to the U.S. Government with Unlimited Rights, as defined in DFARS Part 252.227-7013 or 7014 (Feb 2014). Notwithstanding any copyright notice, U.S. Government rights in this work are defined by DFARS 252.227-7013 or DFARS 252.227-7014 as detailed above. Use of this work other than as specifically authorized by the U.S. Government may violate any copyrights that exist in this work.




Background




Coherent elastic neutrino-nucleus scattering

- A new process that achieves a huge increase in the probability for neutrinos to interact with matter
 - Significant reduction (10-100x) in required target mass
 - Technique recently demonstrated with high energy neutrinos from spallation source



The Super-Kamiokande detector in Japan, which helped establish neutrino has a mass (a violation of the Standard Model).

Target: 50 kilotons of water




16 kg NaI detector from COHERENT collaboration



RICOCHET



Q-Array
Zinc
Superconducting
bolometers
Focus of US
institutions




Cryocube
Germanium
Focus of French
institutions
ERC funding secured


“The first low energy kg-scale CEνNS neutrino observatory combining different targets and different bolometric technologies”



RICOCHET



Q-Array
Zinc
Superconducting
bolometers
Focus of US
institutions



Cryocube
Germanium
Focus of French
institutions
ERC funding secured

“The first low energy kg-scale CEνNS neutrino observatory combining different targets and different bolometric technologies”



Goal and Motivation




Overall goal: Detect neutrinos from a nuclear reactor using coherent scattering

Motivation

- Compact remote sensor of reactor neutrinos
- Basic science applications: sterile neutrinos, dark matter detection, searching for new forces
- Applications to national security: nuclear monitoring, ISR

Nuclear monitoring concept for conventional neutrino detectors



R. Carr et al, arXiv (2018)




Technical approach



Overall goal: Detect neutrinos from a nuclear reactor using coherent scattering

- **Technical challenge: Recoil energy from a nuclear reactor neutrino is 100x smaller than that from a spallation neutron source**
 - Low energy thresholds are required (< 100 eV)
 - Requires better background rejection
- **Proposed solution: Use an array of superconducting target material with highly sensitive amplifiers**
 - Small target size lowers the heat capacity; increases sensitivity to small ΔT
 - An *array* of these detectors increases the target mass to interact with neutrinos
 - Background rates distinguished by time-response in superconductors





Ricochet Prototype Detector





Cryogenic Bolometer (Transition Edge Sensor)



A 30-gram Zn detector prototype

Bolometer Schematic



$$\Delta E \approx 2.35 \sqrt{k_B T^2 C}$$


Lincoln Lab is building arrays of highly-sensitive superconducting amplifiers to enable the first detection of reactor neutrinos via coherent neutrino scattering



Outline



- **Ricochet background**



- **MIT Lincoln Laboratory capabilities**

- **Superconducting amplifiers for Ricochet**



MIT-LL Microelectronics Laboratory




- 70,000 ft² facility: 8100 ft² class 10 & 10,000 ft² class 100
- DoD trusted foundry
- 90-nm CMOS toolset
- Dedicated tools for planarized multilayer Nb process
- State-of-art 3D integration capabilities






Microelectronics Laboratory's Position in the Silicon Fabrication Community





Microelectronics Laboratory's Position in the Silicon Fabrication Community




Microelectronics Laboratory is the most advanced Si-based fab facility in the country dedicated to supporting the research and development needs of the Government




Multi-layer Niobium process

- World's most advanced single-flux-quantum (SFQ) integrated circuit process
- Up to 10 fully-planarized Nb layers
- SFQ circuits with ~1 million Josephson junctions demonstrated
- Also used for Traveling Wave Parametric Amplifiers






High-Q Aluminum process

- Single-layer aluminum process with robust air-bridge crossovers
- Resonator quality factors ~1 million at single-photon excitation
- Fast turn-around and low cost– ideal for prototyping
- Used for high-coherence superconducting qubits





Traveling Wave Parametric Amplifiers





**Demonstrated TWPAs with
> 20 dB gain over 4.25-8.75 GHz band**



Cryogenic Testing at Lincoln Laboratory



- **Testing of SQUID amplifiers leverages room temperature electronics for qubit readout at MIT/LL**
 - **Multiple delusion refrigerators at 15 mK**
 - **Supporting electronics**
 - Arbitrary waveform generators
 - Network analyzers
 - Low noise bias signal generators
 - Cryogenic HEMTs
 - Traveling-wave parameter amplifiers (TWPAs)





Outline





- Ricochet background
- MIT Lincoln Laboratory capabilities
- • Superconducting amplifiers for Ricochet



SQUID Amplifier Arrays for TES Readout



- Traditionally SQUID amplifiers are used to boost signal above the noise temperature of cryogenic HEMTs ($T_N \sim 4$ K)
- *Microwave frequency multiplexing* enables high density arrays with limited control lines
- Similar to the method utilized for qubit readout at Lincoln
- 128 TES readout demonstrated on the NIST SLEDGEHAMMER gamma-ray spectrometer
 - Current noise: $19 \text{ pA}/\sqrt{\text{Hz}}$







SQUID Amplifier Arrays for TES Readout



- Traditionally SQUID amplifiers are used to boost signal above the noise temperature of cryogenic HEMTs ($T_N \sim 4$ K)
- *Microwave frequency multiplexing* enables high density arrays with limited control lines
- Similar to the method utilized for qubit readout at Lincoln
- 128 TES readout demonstrated on the NIST SLEDGEHAMMER gamma-ray spectrometer
 - Current noise: $19 \text{ pA}/\sqrt{\text{Hz}}$
 - Ricochet: targeting $< 3 \text{ pA}/\sqrt{\text{Hz}}$ to enable for detection of $< 100 \text{ eV}$ neutrinos (with 1 kHz bandwidth)






SQUID Amplifier Arrays for TES Readout



- Traditionally SQUID amplifiers are used to boost signal above the noise temperature of cryogenic HEMTs ($T_N \sim 4$ K)
- *Microwave frequency multiplexing* enables high density arrays with limited control lines
- Similar to the method utilized for qubit readout at Lincoln
- 128 TES readout demonstrated on the NIST SLEDGEHAMMER gamma-ray spectrometer
 - Current noise: $19 \text{ pA}/\sqrt{\text{Hz}}$
 - Ricochet: targeting $< 3 \text{ pA}/\sqrt{\text{Hz}}$ to enable for detection of $< 100 \text{ eV}$ neutrinos (with 1 kHz bandwidth)






SQUID Amplifier Arrays for TES Readout




- Traditionally SQUID amplifiers are used to boost signal above the noise temperature of cryogenic HEMTs ($T_N \sim 4$ K)
- *Microwave frequency multiplexing* enables high density arrays with limited control lines
- Similar to the method utilized for qubit readout at Lincoln
- 128 TES readout demonstrated on the NIST SLEDGEHAMMER gamma-ray spectrometer
 - Current noise: $19 \text{ pA}/\sqrt{\text{Hz}}$
 - Ricochet: targeting $< 3 \text{ pA}/\sqrt{\text{Hz}}$ to enable for detection of $< 100 \text{ eV}$ neutrinos (with 1 kHz bandwidth)





SQUID Amplifier Design: Gain Analysis



$$\bullet \frac{dV_o}{dI_{TES}} = V_{IN} \frac{d\Phi}{dI_{TES}} \frac{dL}{d\Phi} \frac{dw_0}{dL} \frac{dS_{21}}{dw_0} \quad \text{Gain}$$

$$\bullet \frac{d\Phi}{dI_{TES}} = M_{IN}$$

- **Need to increase gain to improve sensitivity**
- **Additional requirements:**
 - High quality factors in waveguides
 - Good resonator frequency control
 - Good yield




Initial demonstration of scalable amplifiers




- **Demonstrated scalable superconducting SQUID amplifiers (singles) for bolometric neutrino detection**
 - Microwave multiplexed design
 - High Q resonators that can be densely multiplexed
 - High pattern fidelity with reproducible resonator frequency

Wafer fabricated using LL multi-layer Nb process



Superconducting amplifier prototype






Initial demonstration of scalable amplifiers




- **Demonstrated scalable superconducting SQUID amplifiers (singles) for bolometric neutrino detection**
 - Microwave multiplexed design
 - High Q resonators that can be densely multiplexed
 - High pattern fidelity with reproducible resonator frequency
- **Next step: improve amplifier design to enable detection of 100 eV threshold events**
 - Optimize design parameters for high gain
 - Incorporate Lincoln-fabricated Traveling Wave Parametric Amplifiers (TWPAs)

Wafer fabricated using LL multi-layer Nb process



Superconducting amplifier prototype






Summary



- **MIT-LL is developing scalable superconducting SQUID amplifiers for bolometric neutrino detection**
 - Microwave multiplexed design
 - High Q resonators that can be densely multiplexed
 - Optimizing amplifier parameters for high sensitivity
 - Leveraging TWPA technology
- **Enabling ongoing Ricochet effort to do a first detection of reactor neutrino using the CE ν NS process**



RICOCHET