



Motivation

Why Optical?


- No wires into detector ASIC -> greatly reduced noise from:
 - Parasitic Capacitance
 - Analog to Digital Cross Talk
 - External Sources
- Reduction of Thermal Load into Cryogenic Detectors
- Digitization on detector-side -> greatly increased sensitivity



Scaling Up?



- μ LEDs and OLEDs offer high energy efficiency, long lifespan, and improved contrast and resolution
- Single Photon Avalanche Diodes (SPAD's) and Photodiodes offer high sensitivity and high fidelity
- Creating an optically separated array of LEDs and Photodiodes -> easy scaling

Detector Design and Communication Scheme



Charge-Integrate/Replenish (CIR) Circuit

- Integration of voltage on C_f - ($Q = CV$)
- On when voltage threshold is met, off when voltage goes low
- Width of the Schmitt Trigger output(s) proportional to ΔQ




"Clock-less" Charge Replenishment Scheme

- R_1 and C_1 gives "On-Time", R_2 and C_2 "Off-Time"
- "Replenishment" removes charge from C_f
- "Discharge" re-arms CRS logic
- 555 "Timer" generates LED Trigger pulses

Photonic Back-end

- Silicone Photomultiplier (SiPM) used to generate a signal from LED
- Schmitt Trigger converts raw signal from SiPM to digital pulse
- Digital pulse used for readout system (FPGA, ASIC, ect.)

Testbench Setup



Acknowledgments



This work is supported by the Department of Energy and the Office of Science under award number: DE-SC0011686



Testing Results

Results

- CIR output matched with de-integration on input (across C_f)
- SiPM-side didn't match LED input exactly, but was able to width of the signal correctly
- Number of LED Trigger Pulses varies, but gives roughly the same width overall



Next-Steps

- More work is needed on Charge Replenishment Scheme and Photonic Back-end to successfully implement into a Q-Pix design
- Input noise needs to be minimized to increase sensitivity to targeted fC/replenishment range
- Device needs to be calibrated in cold for "Liquid Noble" testing upon successful bench calibration