

Photoelectric current measurement of plasma grid materials for a compact H⁻ ion source



Mayuko Nishiwaki

Graduate School of Science and Engineering, Doshisha University

Mamiko Sasao(Doshisha univ.), Motoi Wada(Doshisha univ.),
Haruhisa Nakano(NIFS), Katsuyoshi Tsumori (NIFS)




The authors would like to thank H. Hosono for the permission to use C12A7-electride. The C12A7-electride was supplied from AGC inc., and technical support by Naomichi Miyakawa, Satoru Watanabe, and Kazuhiro Ito of AGC Inc. This work was supported by Grant-in-Aid for Scientific Research of JSPS, 19H01883, 17H03512.


Talk outline

- Electride as a Cs free PG material
- Requirements as the PG material
 - High negative ion production probability (low work function)
 - Low material emission
 - Long life in hydrogen/deuterium plasmas
- Purpose of the PG surface diagnostics
- Experimental setup
- Results
 - LED based photoelectric current measurement
 - Change of surface condition by hydrogen plasma exposure
- Summary and outlook

Electride as a Cs-free PG material



- Known as a component of alumina cement, $12\text{CaO}\cdot 7\text{Al}_2\text{O}_3$ (C12A7 in short)
- Composed of 12 positively charged cages in a cubic unit cell.
- And in this cage, C12A7 electride holds an electron.
- Electrically conductive
- Low work function (emitting electron easily)





Talk outline

- Electride as a Cs free PG material
- Requirements as the PG material
 - High negative ion production probability (low work function)
 - Low material emission
 - Long life in hydrogen/deuterium plasmas
- Purpose of the PG surface diagnostics
- Experimental setup
- Results
 - LED based photoelectric current measurement
 - Change of surface condition by hydrogen plasma exposure
- Summary and outlook



Requirements as the PG material

- A PG material should satisfy the following requirements:
 - High negative ion yield for the surface collisions and desorption of hydrogen/deuterium atoms and ions.
 - Robustness against hydrogen/deuterium plasma exposure.
 - Low impurity emission to the hydrogen/deuterium plasmas.
- These characteristics can be evaluated using plasma-surface interaction model.
 - ACAT simulations were done for the corresponding conditions for hydrogen/deuterium plasmas.

Three components: two from surface



Deuterium erodes electride PG



Talk outline

- Electride as a Cs free PG material
- Requirements as the PG material
 - High negative ion production probability (low work function)
 - Low material emission
 - Long life in hydrogen/deuterium plasmas
- Purpose of the PG surface diagnostics
- Experimental setup
- Results
 - LED based photoelectric current measurement
 - Change of surface condition by hydrogen plasma exposure
- Summary and outlook

Purpose of the PG surface diagnostics


- For long term usage of bulk electride PG, deterioration due to long term plasma exposure: impurity accumulation/removal of surface cage structure, must be monitored.
- The PG surface layer can be renewed after confirming the depletion of the electride deposition. (Electride PG can be prepared by through sputtering process.)
- Both operations requires proper time for the PG surface treatment.
- Thus, we need to monitor the electride PG surface condition.

Talk outline

- Electride as a Cs free PG material
- Requirements as the PG material
 - High negative ion production probability (low work function)
 - Low material emission
 - Long life in hydrogen/deuterium plasmas
- Purpose of the PG surface diagnostics
- Experimental setup
- Results
 - LED based photoelectric current measurement
 - Change of surface condition by hydrogen plasma exposure
- Summary and outlook


Experimental setup – Plasma grid

Taper
Structure



Hole diameter : $\phi 4 \text{ mm}$, 6 mm
Thickness : 2 mm
Material diameter : $\phi 34 \text{ mm}$

Plasma grid
(front)



C12A7 electride


Plasma grid
(back)



Molybdenum





Experimental setup - Electride heating system

Heater : Nichrome exotherm
SUS sheath
Thermocouple : K type
SUS sheath
Heater base : Mo
Holder : SUS






Remove the surface layer by heating the sample up.


Experimental setup – Electride heating system







Experimental setup - Electride heating system



Experimental setup - ion source




Experimental setup - ion source




Experimental setup -ion source

After correction





Before correction



Talk outline

- Electride as a Cs free PG material
- Requirements as the PG material
 - High negative ion production probability (low work function)
 - Low material emission
 - Long life in hydrogen/deuterium plasmas
- Purpose of the PG surface diagnostics
- Experimental setup
- Results
 - LED based photoelectric current measurement
 - Change of surface condition by hydrogen plasma exposure
- Summary and outlook

Results -LED based photoelectric current measurement



Comparison of square root of the Quantum Efficiencies of LEDs and Laser.

Results

-Change of surface condition by hydrogen plasma exposure realized with a tungsten hot cathode

The photoelectric current measurement using a LED light (270nm).

Current flowing in a PG : 0.33-0.39pA
(LED : 4.60eV, $I_d = 0.07A$)



Plasma ignition


Gas pressure : 0.55Pa
Arc voltage : 80.1V
Filament : 10.0V, 1.45A



Current flowing in a PG : 0.01-0.03pA
(LED : 4.60eV, $I_d = 0.07A$)

Photoelectric current cannot be measured after the plasma ignition in an arc discharge.

Once the voltage was reduced and re-measured.
Confirmed the reproducibility.



PE bias characteristics of plasma electrode current.

Talk outline

- Electride as a Cs free PG material
- Requirements as the PG material
 - High negative ion production probability (low work function)
 - Low material emission
 - Long life in hydrogen/deuterium plasmas
- Purpose of the PG surface diagnostics
- Experimental setup
- Results
 - LED based photoelectric current measurement
 - Change of surface condition by hydrogen plasma exposure
- Summary and outlook

Summary and outlook

- The work function of electride has been measured successfully using LEDs.
- New ion source, equipped with large window for LED light injection was assembled and being tuned.
- Tungsten filamen may contaminate electride PG surface to increase the work function. (to be confirmed)
- Need to increase of the number of wavelengths of LEDs (275nm, 310nm) used for photoelectric current measurement.
- Experiment with 2.45 ECR to compare the result with W filament discharge.
- Confirmation of Cs/Mo work function with LEDs.

Thank you for your
attention!