

UK Advanced Instrumentation Training

Circuit Design 3 & 4

Dr Weida Zhang @physics.ox.ac.uk 2022 Apr 19






- WorkflowSimulation
 - Analyze -> Block Diagram, Specs
 - Schematic -> Circuit topology, Constraints
 - Layout -> GERBER, BOM, Assembly-files
 - Manufacturing (fabrication, population, assembly)
 - Debug, Characterization -> Reports
 - (Revision)




- Workflow
 - Analyze -> Block Diagram, Specs






Workflow

Schematic -> Circuit topology, Constraints






- Workflow
 - Layout -> GERBER, BOM, Assembly-files



Source: https://www.wellpcb.com/





- Workflow
 - Manufacturing (fabrication, population, assembly)





- Noise
 - Thermal \sim quasi-white, Gaussian, 4kTR; Conductor
 - Shot \sim white, Gaussian, 2e|I|; Semiconductor
 - 1/f, flicker ~ f-depend; Anything
 - Burst ~ 2-value, *f*-depend; Semiconductor








- Interference/Crosstalk
 - Data/Clock dependent ~ non-stationary, f-depend
- Systematic
 - Harmonics, Spurs ~ f-depend; Amp-linearity, ADC, DAC
 - Quantization Noise ~ quasi-white, uniform; ADC
 - Aliasing/Mirror Noise~ Signal x Sinc, uniform; ADC, DAC
 - Clock Phase Noise ~ $1/f^{\alpha}$; resonant, quartz, PLL







- Noise
 - Units PSD vs PSD

$$\bar{P} = \lim_{T \to \infty} \frac{1}{T} \int_{-T/2}^{T/2} \frac{x^2(t)}{R} dt$$

x is the random variable of noise, with the unit of voltage Resistivity R is sometimes ignored to 1, \overline{P} is average power

$$\bar{P} = \int_0^B S_x(f) \mathrm{d}f$$

B is the bandwidth, S_x is the power spectrum density, with the unit of Power per Bandwidth, i.e. dBm/Hz

$$x_{\rm RMS} = \sqrt{\bar{P}R}$$

 $x_{\rm RMS}$ is the root-mean-square of the noise, with the unit of voltage


$$v_n(f) = \sqrt{\overline{S_x(f)}R} = \sqrt{\frac{\bar{x}^2}{RB}}$$
 This is only in white noise, $v_n(f)$ is the voltage spectrum density, with the unit of V/\sqrt{Hz}




- Noise
 - Conversion
 - $0dBm = 0.632V_{PP} = 0.233 V_{RMS}$
 - Quantify and Comparison



$$v_n(f) = \sqrt{\overline{S_x(f)}R} = \sqrt{\frac{\bar{x}^2}{RB}}$$






- v_n as a number gives floor
- x_{RMS} at low frequency tells flicker

NOISE PERFORMANCE				
Input Voltage Noise	f = 0.1 Hz to 10 Hz	150	150	nV p-p
	1/f noise corner	6	6	Hz
	f = 100 Hz	7	7	nV/√Hz
Over-The-Top	f = 100 Hz, V _{CM} > +V _S	8	8	nV/√Hz
Input Current Noise	f = 100 Hz	0.5	0.5	pA/√Hz
Over-The-Top	f = 100 Hz, V _{CM} > +V _S	5	5	pA/√Hz




- Noise
 - Paths
 - Signal Input
 - Resistive Components
 - Semiconductor Devices
 - Non-Linear (not LTI)
 - Power Supplies
 - Indirect Coupling






- Noise
 - Paths
 - Signal Input



• Antenna, transducer

- -> matching network
- Previous Stage of Amps

-> termination



Source: Texas Instruments

$$F_n = F_1 + \frac{F_2 - 1}{G_1} + \frac{F_3 - 1}{G_1 G_2} + \cdots$$



f(Hz)

f(Hz)


f(Hz)


f(Hz)

fs

Circuit Design, Noise, Grounding

- Noise
 - Paths
 - Signal Input
 - ADC





fs/M

2fs/M


(d)

- Quantization ENOB
- Aliasing

$$x[n] = \sum_{n} \int s(t)\delta(t - nT_{S})dt$$




- Noise
 - Paths
 - Signal Input




- DAC
 - Quantization ENOB
 - Mirror/Image

$$s(t) = \sum_{n} x[n] * rect\left(\frac{t}{T_{S}}\right)$$







- Noise
 - Paths
 - Resistive Components
 - Semiconductor Devices





- Noise
 - Paths
 - Non-Linear (not LTI)









- Noise
 - Paths
 - Power Supplies
 - Indirect Coupling


Power integrity






- Noise
 - Paths
 - Power Supplies
 - Indirect Coupling








Grounding





Transmission Line Theory

$$v(z,t) = L\Delta z \frac{\partial i(z,t)}{\partial t} + v(z + \Delta z,t)$$
$$i(z,t) = C\Delta z \frac{\partial v(z + \Delta z,t)}{\partial t} + i(z + \Delta z,t)$$




$$\frac{\partial v(z,t)}{\partial z} = -L \frac{\partial i(z,t)}{\partial t}$$
$$\frac{\partial i(z,t)}{\partial z} = -C \frac{\partial v(z,t)}{\partial t}$$


$$\frac{\partial^2 V}{\partial t^2} - u^2 \frac{\partial^2 V}{\partial x^2} = 0$$

$$\frac{\partial^2 I}{\partial t^2} - u^2 \frac{\partial^2 I}{\partial x^2} = 0$$

$$u = \frac{1}{\sqrt{LC}}$$




$$egin{split} V(x) &= V_1 e^{-jkx} + V_2 e^{+jkx} \ &I(x) &= rac{V_1}{Z_0} \, e^{-jkx} - rac{V_2}{Z_0} \, e^{+jkx} \ &Z_0 &= \sqrt{rac{L}{C}} \end{split}$$






- Signal Integrity
 - Designing and Maintaining Trace Structure
 - Termination



impedance discontinuities at both ends (right).

Source: Keysight





Scattering Parameter (S-Parameter)




$$\left(egin{array}{c} b_1 \ b_2 \end{array}
ight) = \left(egin{array}{cc} S_{11} & S_{12} \ S_{21} & S_{22} \end{array}
ight) \left(egin{array}{c} a_1 \ a_2 \end{array}
ight).$$

 $S_{11}\,$ is the input port voltage reflection coefficient

 $S_{12}\,$ is the reverse voltage gain


 $S_{21}\,$ is the forward voltage gain

 $S_{22}\,$ is the output port voltage reflection coefficient.






Scattering Parameter (S-Parameter)






Matching Network



Source: SiLabs





Simulation of Amplifier Design






Clock Jitter/Phase noise in Digital System/Comms








Clock Jitter/Phase noise in DAQ






Clock Jitter/Phase noise



Source: NIST




Phase Locked Loop





How to read datasheet



IPS output of 29 dBm, yet requires only 70 mA from a 7 V supply: The P1dB output power of 14.5 dBm enables the LNA to function as a local oscillator (LO) driver for balanced, I/Q, or Data Sheet

HMC1049LP5E

SPECIFICATIONS $T_A = 25^{\circ}C, \ V_{DD} = 7 \ V, \ I_{DD} = 70 \ mA^{1}.$										
Table 1.										
Parameter	Min	Тур	Max	Min	Тур	Max	Min	Тур	Max	Unit
FREQUENCY RANGE	0.3		1	1		14	14		20	GHz
GAIN	13.5	16.5		12	15		10	13		dB
Gain Variation Over Temperature		0.006			0.019			0.017		dB/°C
NOISE FIGURE		2.5	3.5		1.8	2.5		2.7	4.0	dB
RETURN LOSS										
Input		15			13			14		dB
Output		8			15			13		dB
OUTPUT										
Output Power for 1 dB Compression (P1dB)		15			14.5			13		dBm
Saturated (PSAT)		18			17.5			16		dBm
Output Third-Order Intercept (IP3) ²		31			29			26		dBm
TOTAL SUPPLY CURRENT		70			70			70		mA

¹ Adjust V_{GG} between -2 V to 0 V to achieve I_{CD} = 70 mA typical.

² Measurement taken at Pour/tone - 8 dRm.

